



		Lauson Part No.	LCT Ref. No.		Lauson Part No.	LCT Ref. No.
3	Muffler Assembly-Snow	02031	SKSN0203.1	30	Crankcase Cover Assy	20836001 SK2083600.1
6	Snow Carburetor Assy	03131	SKSN0313.1	31	Black Oil Dipstick	20837111 SK2083711.1
8	Fuel Primer Bulb with Hose	03061	SKSN0306.1	34	Spark Plug Boot	46911 SKSN4691.1
10	Electric Starter Assy	04111	SKSN0411.1	36	Governor Arm Assy	20830001 SK2083000.1
10A	European 230V Elec Starter	04131	SKSN0413.1	37	Governor Shaft	20831001 SK2083100.1
11	Key Switch Assy	04011	SKSN0401.1	38	Governor Gear Assy	20829001 SK2082900.1
12	CDI Box	04041	SKSN0404.1	39	Camshaft	20816001 SK2081600.1
17	Recoil Starter Assy-Round	06002	SKSN0600.2	40	Cylinder Head Assy	20810001 SK2081000.1
18	Starter Cup Small	06012	SKSN0601.2	41	Spark Plug	20838101 SK2083810.1
19	Snow Starter Grip	06031	SKSN0603.1	44	Piston And Rod Assy	20814001 SK2081400.1
20	Blower Housing Assembly Electric Start - Snow (Black)	06021	SKSN0602.1	46	Vapor Shield	01551 SKSN0155.1
20A	Blower Housing Assembly Manual Start - Snow (Black)	06121	SKSN0612.1	47	Seal Kit	20839001 SK2083900.1
21	Shield, Cylinder	06081	SKSN0608.1	48	Wire Harness	01611 SKSN0161.1
22	Shield, Flywheel-Elec. Start (If Equipped)	06051	SKSN0605.1	49	Crankshaft	20818001 SK2081800.1
22A	Shield, Flywheel-Man. Start	06071	SKSN0607.1	50	Speed Control Bracket	01501 SKSN0150.1
23	Valve Cover	20845001	SK2084500.1	52	Rocker Arm Kit	20811001 SK2081100.1
26	Elec. Start Flywheel Assy	04051	SKSN0405.1	53	Push Rod Kit	20810011 SK2081001.1
26A	Man. Start Flywheel Assy	20817001	SK2081700.1	54	Cylinder Assembly	00012 SKSN0001.2
27	High Oil Fill Tube Assy	20837011	SK2083701.1	56	Gasket Kit	20843001 SK2084300.1
28	Flywheel Fan	20840001	SK2084000.1	57	Fuel Hose Kit	20860011 SK2086001.1
29	Ignition Coil Assy	20825003	SK2082500.3	62	Non-Removable Oil Plug	20837051 SK2083705.1
				65	Oil Drain Plug Kit	20899111 SK2089911.1

rev. 1/11/11

